Searle N2DQ

Installation and Maintenance Instructions ENGLISH

1. HEALTH AND SAFETY
This concerns the hazards, which may be encountered when installing and maintaining this equipment. It is therefore important that these instructions are followed.

Before installation
Ensure that:
a) the voltage, working fluid and the maximum working pressure stated on the product nameplate is suitable for the working environment.
b) the proposed method of mounting is adequate to support the total operational weight of the unit.

During installation and maintenance
Ensure that:
a) the unit is installed and maintained by qualified personnel only.
b) the electrical supply is isolated and secured from accidental re-connection.
c) the working area is adequately ventilated.
d) the temperature of coils with vinyl coated fins does not exceed 150°C (e.g. during brazing) as toxic fumes would be produced.

2. INSTALLATION
General
Upon receipt, the units should be visually inspected and the supplier notified (within seven days) of any damage or shortages. Units are not portable and are only for permanent installation. Electrical screw terminals in control panels and motor mountings should be checked for security.

Location
To ensure optimum performance, the condensing unit should be situated to give uniform air distribution across the coil. Obstructions to airflow should be minimised.
Coils should ideally be shaded from the sun.
Consideration should also be given to servicing requirements - there should be at least 600mm clearance on the right hand side of the units, and access panels must be clear of obstruction.

Floor/Roof Mounting
When Floor Mounted a gap of 250mm **must** be left between the rear of the unit and the nearest wall.
Fixing holes are provided in the feet for securing the condensing unit to a plinth. If the condensing unit is roof mounted, it is recommended that isolation material be used between the feet of the unit and the roof itself.

Guarding Cages
Floor mounted guard cages are available for individual units where additional protection to the installation may be required (contact your supplier for further details).


Pipework
Pipework to and from the unit should be selected to suit the application and not the connection size of the unit. It should be supported independently from the unit and in a way that prevents the transmission of vibration to the unit. A competent engineer should install refrigerant pipework to a high standard of refrigeration practice.

Electrical
Electrical components are located in an enclosure, situated on the front RH side of the unit and behind a lift-off service panel. Always ensure that the electrical supply to the unit is isolated before removing this panel. All electrical components are tested during the manufacturing process.
The electrical supply to the unit must be taken from a correctly sized (and motor rated) main circuit breaker or fuse box, corresponding to the current shown on the unit's nameplate.

Function of Controls
(Please refer to the relevant wiring diagram in Sect. 10)


a) Unit isolation - is situated behind a swivel plate cover on the main control box cover.
b) HP/LP - The HP switch is to prevent overpressure within the system. It should only operate under fault conditions. The LP switch is to prevent too low a pressure. Pressure switches should be set to the required operating limits during commissioning. Do not adjust these switches outside of the acceptable operating limits, (see section 4).
c) FSC - The fan speed controller is used to control the unit's head pressure under low ambient conditions. As the ambient temperature falls the fan speed is reduced to maintain head pressure.

Adjustment of FSC – Control Point (2 Fan Units)
The Fan Speed Controller is fitted on the rear port of the receiver outlet valve, and is factory set to maintain 39°C (17 barg R404A), if the desired Mid point differs from the factory setting it can be adjusted as follows:



Adjustment of FSC – Control Point (4 Fan Units)
The Fan Speed Controller is fitted on the control panel RH side, and uses a pressure sensor module mounted on the rear port of the receiver outlet valve, and is factory set to maintain 36.5°C (15.5 barg R404A). If the operating pressure falls below this setpoint the fans will

it can be adjusted as follows: (See diagram)
a. Remove sealing cap (3).
b. Insert enclosed 2mm allen key (2) into adjustment screw (1).
c. Turn allen key clockwise (+) to increase, or counterclockwise (-) to decrease pressure setting.
Do not turn adjustment screw more than 3 turns clockwise (+3).
1 turn causes a pressure change of approximately 2.6 bar.



d) Compressor Manual Motor Starter/Overloads – Each compressor is supplied via a MMS/Overload, which should be set to the maximum running current as shown on the compressor nameplate during commissioning. In the event of too high a current or phase loss occurring the MMS will trip out and stop the compressor, requiring a manual reset.


e) Compressor Contactor – Each compressor supply is switched via a contactor. The contactor is controlled via the Compressor Step Controller, and integrates the compressor safety chain of the HP/LP's and MMS/Overloads.

f) Digital Scroll Solenoid – The lead compressor on all units is a digital scroll compressor with a variable capacity. There is a right angled solenoid valve connected to the head of the digital compressor and the suction line. The main controller cycles this solenoid to load and unload the digital compressor to modify its capacity in 20 second cycles.


g) Compressor Step Controller – the starting and stopping of the compressors is controlled by an electronic controller. The controller monitors the suction pressure via a transducer and brings compressors in or out to maintain the suction pressure about the desired setting. Discharge pressure is also monitored but not used for control purposes.

Units are fitted with an EC2 controller. This controller will modulate the capacity of the Digital compressor from 10 to 100%, and run the second compressor to suit the load required.
IMPORTANT : All EC2 controllers are fitted with a dedicated 24V transformer that is not earthed. The EC2 controllers must not be earthed. Do not fit any other electrical equipment to the EC2's transformer.

Suction Pressure Control EC2-552
2 control loops with the same suction pressure setpoint 'P0' modulate the compressors.



The dead band control loop with dead band 'P1' switches the single stage compressor on or off, whereas a Pi control loop modulates the Digital Scroll base load compressor between approximately 10% and 100% capacity. Being the base load compressor, the Digital Scroll Compressor will never be switched off while the single stage compressor remains on.
Connections to the controller as below, (See wiring diagrams for further info.)
EC2-552



Set-up / Parameter Modification using the Keypad
The controller is factory set to maintain a suction pressure of 3.5 BarG on HT units, and 0.8 BarG on LT units, this can be modified during commissioning as described below.
WARNING: Do not set the controller outside of the application limits as shown in section 4.

The parameters can be accessed via the 4-button keypad. The configuration parameters are protected by a numerical password. The default password is "12".
Please refer to the parameters table on page 5
To select the parameter configuration:

1. Press the Prg button for more than 5 seconds
2. A flashing 0 is displayed
3. Press or until 12 is displayed; (password)
4. Press Sel to confirm password
5. The first modifiable parameter code is displayed (/1).
6. Press or to show the code of the parameter that has to be changed;
7. Press Sel to display the selected parameter value;
8. Press or to increase or decrease the value;
9. Press Sel to temporarily confirm the new value and display its code.
10. Repeat the procedure from point 6 to modify any other parameters.
11. Press Prg to confirm the new values and exit the parameters modification procedure.

Temporary Display Of Data:
It is possible to temporarily display the values of the different sensors. This is a useful feature when initially setting-up the system without the aid of the WebPages.
Press the Sel sequentially. The value displayed on the screen corresponds to the number corresponding to the /1 parameter. (Action only valid when parameter H2 = 3)

Special Functions:
The Special Functions can be activated by:

1. Press and together for more than 5 seconds. A flashing 0 is displayed.

2. Press or until the password is displayed (default = 12). If password was changed, select the new password.

3. Press Sel to confirm password , A 0 is displayed and the Special Function mode is activated.

4. Press or to select the function. The number of special functions is dynamic and controller dependent. See list below.

5. Press Sel to activate the function without leaving the special function mode.


6. Press Prg to activate the function and leave the special function mode.

Most of the Special Functions work in a toggle mode, the first call activates the function, and the second call deactivates the function.

The indication of the function can only be displayed after exiting the special function mode.

• 0: Display test function
• 1: Displays the current TCP/IP address
• 2: Set the controller TCP/IP address to the default value: 192.168.1.101
• 3: Resets all parameters to the factory default setting. The controller will indicate “oF” during the reset.

The data to be shown on the display can be selected by the user. In case of an alarm, the alarm code is displayed alternately with the selected data. The user can inhibit the alarm code. Press the Sel button to scroll through all possible displayable data.
The display will show for one second the numerical identifier of the data and then the selected data. After two minutes the display will return to the by parameter /1 selected data.



Indications On The Display:
Compressor Controller
• State
• Alarm in combination with alarm message and alarm LED
• Suction pressure or saturation temperature from suction pressure
• Parameter
Other display
• Pressure: Pressure value in bar (g)
• Alarm: Alarm condition
• IR: IR communication enabled
Alarm Codes
‘HP’ High pressure alarm
Controller 1: suction pressure higher than the maximum limit
Controller 2: condensing pressure higher than the maximum limit (Not Applicable).
‘IP’ Low pressure alarm
Controller 1: suction pressure lower than the minimum limit
Controller 2: condensing pressure lower than the minimum limit
‘d1’ Discharge temperature alarm
Digital scroll only: Discharge end temperature is too high
‘EP’ Error pressure
Controller 1: suction pressure sensor failure
Controller 2: condensing pressure sensor failure (N/A)
‘Fr’ Fast recovery alarm
Controller 1: fast recovery from low suction pressure
Controller 2: fast recovery from low condensing pressure (N/A)
‘hr' High discharge pressure alarm
Controller 1: high discharge pressure recovery
Controller 2: high discharge pressure recovery (N/A)
‘rE’ Emergency run
Controller 1: runs with c6 numbers of compressors
Controller 2: runs with c6 numbers of fans (N/A)
‘E1’ Feedback alarm 1
Controller 1: digital input associated with compressor 1 has changed into alarm state (safety chain)
Controller 2: digital input associated with fan(s) has changed into alarm state (safety chain) (N/A)
‘E2’ Feedback alarm 2
Controller 1: digital input associated with compressor 2 has changed into alarm state (safety chain) (N/A)
‘n1’ Service alarm 1
Controller 1: compressor 1 operating time higher than run limit (A9)
Controller 2: fan operating time higher than run limit (A9) (N/A)
‘n2’ Service alarm 2
Controller 1: compressor 2 operating time higher than run limit (A9)
Er Data error
Data send to the display is out of range
Messages
‘---‘ No data to display
The display will show an “---” at node start up and when no data is send to the display.
‘In’ Reset to default values activated
The display will show an “In” when the factory default configuration data set
is initialized.
‘Id’ Wink request received
The display will show a flashing “Id” when the wink request was received. The flashing “Id” will be shown on the display until the service button will be pressed, or a 30 min delay timer will expire or a second wink request is received. This function is action only when using SNMP protocol. The node is offline and no application is running. This is the result of a network management command and will happen for example during node installation.

WARNING: Do not set the controller outside of the application limits as shown in section 4.

For a full description of controller settings please refer to the table on page 5.

‘L’ version units only
h) DTC - 'L' models use ZF EVI scroll compressors. Units are fitted with a Plate Heat Exchanger to super sub cool the liquid from the condenser, and provide vapour injection to the compressors. A solenoid valve on each compressor vapour injection port is slaved to the compressor contactors and operates when the compressor runs.
f) Klixon - discharge temperature protector, switches the compressor off if the discharge temperature exceeds a pre-set maximum (auto re-set).
All units
g) Pressure Relief Valve - fitted in the side of the liquid receiver. If the unit is not located externally in open air the relief valve outlet must be piped away to open air. Regular maintenance is required see section

6. Maintenance *Every 3-6 Months.*

3. EVACUATION AND CHARGING

Before operating the unit for the first time, check that all guards, motors, mountings and electrical covers are secure, and that fans rotate freely. The unit has been leak tested, dehydrated and filled with a holding charge of "dry air" during manufacture.

The entire system should be evacuated prior to charging as follows:

- The right hand panel should be removed to provide access to the compressor shut off valves with service ports.
- Connect a vacuum pump to the 1/4" flare connections on each compressor shut-off valve.
- These valves will be in a fully back-seated position in the unit as supplied. The valve spindles should be screwed in a few turns to open up the ports.
- Evacuate the system to below 225 microns (0.3mbar). The pump should be isolated and system pressure monitored. A rapid continuous rise would indicate a leak in the system.
- During the evacuation process, the crankcase heater should be switched on.

Note: To ensure that compressor is not operated during evacuation, the compressor overloads / manual motor starters must be in the off position.

DO NOT START THE COMPRESSOR UNDER VACUUM.

The unit should be charged with the specified refrigerant (N2DQ 'L' Units R404A, 'N2DQ M' Units R404A/R407C/R134A), until the sight glass is just clear at the normal operating condition. If after charging the unit is left with the power supply turned off, turn on the power supply for a minimum period of three hours before the unit is switched on. This will ensure that the compressor sump is warm and free from liquid refrigerant.

IMPORTANT

N2DQ Scroll compressors, like several other types of compressor, will only compress in one rotational direction. Three-phase compressors will rotate in either direction, depending upon phasing of the power to T1, T2 and T3. Since there is a possibility of connecting power in such a way as to cause rotation in the reverse direction, it is important to check this. Verification of rotation direction can be made by observing that suction pressure drops and discharge pressure rises when the compressor is energised. Reverse rotation results in a sound level above that of the correct rotation direction, as well as a substantially reduced current draw.

Oil Charge

The compressors are pre charged with Polyolester oil. Following initial start-up, some of this oil will migrate to other areas of the system. Ensure the oil charge in the system is adequate as follows :-

- N2DQ 'M' models utilise an oil balance line between compressors, ensure the oil balance line sightglass level is 1/2 full when the compressors are not running.
- N2DQ 'L' models are fitted with a separator reservoir, ensure the oil charge is adequate to show in the upper sight glass when the compressors are not running.

Note: on N2DQ 'M' models with oil balance lines, the oil level may show as empty when only one compressor is running, this is normal. The true oil level will show when both compressors are running, or both are at rest.

Only suitable Polyolester oil, such as Mobil EAL Arctic 22 CC (or equivalent), should be used.

4. OPERATING LIMITS

The HP/LP switch must be set to prevent the unit from operating outside of its application limits.

The LP switch and Step Controller must not be set any lower than the figures below:

R404A & R407C

Unit Range	Minimum SST °C R404A R407C	LP Cut out BarG R404A	LP Cut out BarG R407C	Maximum HP Cut out BarG R404A R407C
'MS'	-20	2	1.7	25.2
'LS'	-40	0.35	N/A	25.2

R134A

Unit Range	Minimum SST °C R134a	LP Cut out BarG R134a	Maximum HP Cut out BarG R134a
'MS'	-20	0.37	14.4
'LS'	-20	0.37	14.4

The LP differential setting must be set high enough to prevent short cycling of the unit.

The LP Cut-Out pressure is the LP range setting minus the LP differential setting.

The HP switch must be set at 0.9 x the PRV setting for all refrigerants. As standard units are fitted with a PRV set to 28 BarG, the HP switch **must not** be set higher than 25.2 BarG.

For R134a refrigerant a lower pressure 16 BarG PRV is available, part number 200-200-528, the HP switch **must not** be set any higher than 14.4 BarG.

Multiple Evaporator Applications

If the condensing unit is connected to multiple evaporators operating independently of one another, it is essential that the saturated suction temperature remains within the operating limits when the minimum number of evaporators are running.

If the saturated suction temperature falls close to or below the operating limits for medium temperature 'M' units when the minimum number of evaporators are running, the use of 'L' units, or other Searle condensing unit products should be considered.

5. MAINTENANCE

WARNING! THE UNIT MUST BE ELECTRICALLY ISOLATED BEFORE MAINTENANCE WORK IS UNDERTAKEN

The following routine maintenance is required:

Every 3-6 months

The condenser should be cleaned with a soft brush to ensure correct operation of the condensing unit. When the condenser coil is obstructed by dirt or rubbish, the unit will experience high condensing temperatures which will result in higher running costs, loss of compressor efficiency and ultimately overheating of the compressor and/or condenser fans.

The pressure relief valve should be inspected for any pressure release. If a release has occurred or there is a requirement by the customer maintenance schedule the relief valve should be changed.

The PRV MUST be changed every 5 years.

Every 12 months

Check security of fixings, especially the fan and motor mounting. Check refrigerant pipeline for damage and leaks. Check motor (fans should rotate freely).

Check torque settings of compressor rotalock valves (see table below).

When necessary

Clean the fins, guard and general casework. Care must be taken when cleaning the fins to prevent damage. It is recommended that a soft brush and mild detergent solution be

used.
High-pressure spray washing of the unit must not be undertaken, as damage to fin coatings and components will occur. Low-pressure spray washing using specialist coil cleaning solutions is recommended.

WARNING! SAFETY GOGGLES MUST BE WORN DURING THIS OPERATION.

6. INVALIDATION OF GUARANTEE
Searle accepts no liability, according to Searle's terms and conditions of sale, for loss or damage arising as a result of:

(i) Failure to install, set up or put to work any part of equipment in the manner specified in the I&M instructions, or
(ii) Failure to maintain the equipment in the manner specified in the I&M instructions, or
(iii) Replacement parts, additional parts or accessories supplied by persons other than Searle having been incorporated into, or attached to the equipment, or
(iv) The equipment having been adapted for use, operated or used in such a way as does not conform to Searle's recommendations.

7. REFRIGERATION COMPONENTS LIST

Unit Model		Refrigeration Components							
		Digital Scroll Compressor 1	Non-Digital Compressor 2	Filter Drier Sight Glass	Fan Set	Oil Separator	PRV (28 Bar)	Receiver	Rotalok Valve Set
N2DQ Model	N2DQ60-3MS-D	200-200-163	200-200-139	200-452-119	231-945-106	200-200-415	200-200-040	200-616-039	200-200-610
	N2DQ60-3MS-E	200-200-163	200-200-139	200-452-114	231-945-106	200-200-417	200-200-040	200-616-039	200-200-610
	N2DQ90-3MS-E	200-200-165	200-200-141	200-452-114	231-945-106	200-200-417	200-200-040	200-616-039	200-200-610
	N2DQ36-3LV-E			200-452-119	231-945-106	200-604-019	200-200-040	200-616-039	200-200-610

8. ELECTRICAL COMPONENTS LIST

Unit Model		Electrical Components						
		Contactor	Overload Auxiliary	Overload	Isolator	EC2 Controller	Fan Speed Controller	Crankcase Heater
N2DQ Model	N2DQ60-3MS-D	216-131-007	200-200-744	200-200-740 200-200-741	216-112-302	200-800-240 & 200-800-244	216-154-158	200-200-103
	N2DQ60-3MS-E	216-131-007	200-200-744	200-200-740 200-200-741	216-112-302	200-800-240 & 200-800-244	216-154-156	200-200-103
	N2DQ90-3MS-E	216-131-007	200-200-744	200-200-740 200-200-741	216-112-302	200-800-240 & 200-800-244	216-154-156	200-200-103
	N2DQ36-3LV-E	216-131-007	200-200-744	200-200-741	216-112-302	200-800-240 & 200-800-244	216-154-156	200-200-103

9. Compressor Rotalock Valve Torques
Check compressor rotalocks as described in the maintenance section ‘Every 12 months’ (p4).

Unit	Discharge		Suction	
	Size	Torque	Size	Torque
All N2DQ units	1" x 14	60 - 70 Nm	1 1/4" x 12	90 - 100 Nm

Note: connection sizes are the threaded spud connection size, not the pipework size.

10. N2DQ EC2 Controller Parameters

Controller 1 (Compressor controller)

/	DISPLAY PARAMETERS	Min	Max	Unit	Def	Individ.
/1	Value to be shown on display 0 = compressors and fans states (controller 1 and 2) 1 = suction pressure (bar) 2 = saturation temperature from suction pressure (°C) 3 = condensing pressure (bar) 4 = saturation temperature from condensing pressure (°C) 5 = Digital Scroll capacity (%) 6 = fan speed (%) 7 = Digital Scroll discharge temperature (°C)	0	7	-	0	

P	SET-POINT PARAMETERS - C1					
P0	Pressure set-point (suction) for compressor circuit	-1.0	50	bar	3.0	
P1	Pressure band (control band for P/PI, dead band for dead band control mode)	0.0	50	bar	2.0	
P3	Fast recovery from low pressure	-9.9	50	bar	-9.9	
P8	High discharge pressure recovery	-9.9	50	bar	50	
t	**TIME PARAMETERS**					
t1[1]	Time delay before adding capacity	0	99	10sec	3	
t2[1]	Time delay before removing capacity	0	99	10sec	3	
t3[1]	Compressor minimum on time	0	99	10sec	6	
t4[1]	Compressor minimum off time	0	99	10sec	6	
t5	Maximum compressor switching	0	199	1/hr	0	
A	**ALARM PARAMETERS - C1**					
A2	Minimum suction pressure alarm limit	-1.0	50	bar	1.0	
A3	Maximum suction pressure alarm limit	-1.0	50	bar	6.0	
A4[1]	Delay time for minimum pressure alarm limit	0	99	10sec	0	
A5[1]	Delay time for maximum pressure alarm limit	0	99	10sec	0	
A6	High discharge temperature cut-out cut-in = cut-out – 10°C	100	140	°C	130	
A8[1]	Compressor serial alarm delay	0	99	10sec	0	
A9[2]	Compressor run limit	0	99	10 000hr	0	
u	**STEP ENABLE PARAMETERS - C1**					
u0	Reset operating time 0 = do nothing 1 = reset operating time compressor 1 2 = reset operating time compressor 2 3 = reset operating time all compressors	0	3	-	0	
u1	Enable/disable compressor 1	0	1	flag	1	
u2	Enable/disable compressor 2	0	1	flag	1	
c	**APPLICATION PARAMETERS - C1**					
c1	Number of compressors	1	2	-	2	
c4	Compressor 1 control mode 0 = compressor 1 in standard control loop 1 = compressor 1 act as base load compressor 2 = compressor 1 is a digital scroll compressor & base load	0	2	-	2	
c5	Compressor switch logic 0 = FILO logic (First In, Last Out) Capacity demand: Adds first compressor out of available compressors. (= compressors where min off time (t4) is fulfilled) Capacity excess: Removes last compressor out of available compressors. (= compressors where min on time (t3) is fulfilled) 1 = Rotation enabled Capacity demand: Adds compressor with lowest runtime out of available compressors. (= where min off time (t4) is fulfilled) Capacity excess: Removes compressor with highest runtimes out of available compressors. (= where min on time (t3) is fulfilled)	0	1	flag	0	
c6	Number of compressors to switch on in case of sensor failure	0	2	-	0	
F	**MODULATING PARAMETERS - C1**					
F2	Minimum output value	10	100	%	20	
F3	Maximum output value	10	100	%	100	
F6	PWM rate (Digital scroll)	10	20	sec	20	
r	**SENSOR PARAMETERS - C1**					
r0	Suction pressure sensor minimum value	-1.0	50	bar	0.0	


	SENSOR PARAMETERS - C1 (continued)	Min	Max	Unit	Def	Individ.
r1	Suction pressure sensor maximum value	-1.0	50	bar	18.0	
r2	Pressure offset for suction pressure	-1.0	1.0	bar	0.0	
r3	Refrigerant type 0 = no temperature conversion; 1 = R22; 2 = R134a; 3 = R507; 4 = R404A; 5 = R407C	0	5	-	4	

Controller 2 (Fan controller)


P	SET-POINT PARAMETERS - C2					
P0	Pressure set-point (condensing) for fan circuit	-1.0	50	bar	14.0	
P1	Pressure band (control band for P/PI, dead band for dead band control mode)	0.0	50	bar	4.0	
A	**ALARM PARAMETERS - C2**					
A2	Minimum condensing pressure alarm limit	-1.0	50	bar	10.0	
A3	Maximum condensing pressure alarm limit	-1.0	50	bar	27	
A4[1]	Delay time for minimum pressure alarm limit	0	99	10sec	0	
A5[1]	Delay time for maximum pressure alarm limit	0	99	10sec	0	
A9[2]	Fan run limit	0	99	10kHr	0	
u	**STEP ENABLE PARAMETERS - C2**					
u0	Reset operating time 0 = do nothing 1 = reset operating time fan 1	0	1	-	0	
u1	Enable/disable fan 1	0	1	flag	1	
c	**APPLICATION PARAMETERS - C2**					
c6	Fan behaviour on in case of sensor failure 0 = Analog output 0% (0 V) 1 = Analog output 100% (10 V)	0	1	-	0	
F	**MODULATING PARAMETERS - C2**					
F2	Minimum output value	0	100	%	0	
F3	Maximum output value	0	100	%	100	
r	**SENSOR PARAMETERS - C2**					
r0	Condensing pressure sensor minimum value	-1.0	50	bar	0.0	
r1	Condensing pressure sensor maximum value	-1.0	50	bar	30	
r2	Pressure offset for condensing pressure	-1.0	1.0	bar	0.0	
H	**OTHER PARAMETERS**					
H2	Keyboard and IR remote control 0 = all disabled (Caution, access to controller only via network possible) 1 = Keyboard enabled 2 = IR remote control enabled 3 = Keyboard and IR remote control enabled	0	3	-	3	
H3	IR remote control access code	0	199	-	0	
H5	Password	0	199	-	12	

[1] These values have a resolution of 10 sec, on the local display. Ex. a value 2 means 20 sec.
[2] These values have a resolution of 10.000 hours, on the local display. Ex. a value 2 means 20.000 hours.


11. WIRING DIAGRAMS N2DQ ALL UNITS



12. DIMENSIONS



Case D (N2DQ60-3MS-D)



Case E (N2DQ60-3MS-E & N2DQ90-3MS-E & N2DQ36-3LV-E)

13. SPECIFICATION

Model	Combined Compressors			Max Surge	Fans 230V/1ph/50Hz				Conn. Sizes		Liquid Receiver	Dry Weight	Dimensions			Fixing Ctrs		C S
	Power*	FLC	LRA		No. Fans	FLC	SC	Power	Suct.	Liquid.			Height	Width	Depth	Width	Depth	
	(kW)	3ph (A)	3ph (A)	3ph (A)		(A)	(A)	(kW)	(")	(")	(L)	(kg)	(mm)	(mm)	(mm)	(mm)	(mm)	
N2CQ18-3LX/S-D	3.82	12.0	80	48.0	2	2.0	3.6	0.28	1 1/8	5/8	18.0	218	1192	2260	600/540	2 x 750	570	
N2CQ22-3LX/S-D	4.65	14.0	92	55.0	2	2.0	3.6	0.28	1 1/8	5/8	18.0	220	1192	2260	600/540	2 x 750	570	
N2CQ26-3LX/S/V-D	5.10 (LX/S) 6.12 (LV)	16.0	104	62.0	2	2.0	3.6	0.28	1 3/8	5/8	18.0	241	1192	2260	600/540	2 x 750	570	
N2CQ30-3LX/S-D	6.11	20.0	128	76.0	2	2.0	3.6	0.28	1 3/8	5/8	18.0	251	1192	2260	600/540	2 x 750	570	
N2CQ36-3LX/S/V-E	7.62 (LX/S) 8.98 (LV)	24.0	148	90.0	4	4.0	7.2	0.56	1 3/8	7/8	18.0	255	1192	2260	600/540	2 x 750	570	
N2CQ48-3LX/S/V-E	9.60 (LX/S) 11.37 (LV)	32.4	198	119.0	4	4.0	7.2	0.56	1 5/8	7/8	18.0	435	1192	2260	600/540	2 x 750	570	
N2CQ66-3LX/S/V-E	13.65 (LX/S) 16.53 (LV)	44.6	278	160.3	4	4.0	7.2	0.56	1 5/8	7/8	18.0	435	1192	2260	600/540	2 x 750	570	
N2CQ30-3MX/S-D	3.64	9.6	52	32.9	2	2.0	3.6	0.28	1 1/8	5/8	18.0	203	1192	1560	600/540	810	570	
N2CQ38-3MX/S-D	4.30	13.0	64	40.5	2	2.0	3.6	0.28	1 1/8	5/8	18.0	209	1192	1560	600/540	810	570	
N2CQ42-3MX/S-D	5.28	14.4	80	49.2	2	2.0	3.6	0.28	1 1/8	5/8	18.0	220	1192	1560	600/540	810	570	
N2CQ52-3MX/S-D	6.14	17.7	92	56.9	2	2.0	3.6	0.28	1 3/8	5/8	18.0	222	1192	1560	600/540	810	570	
N2CQ60-3MX/S-D	7.22	20.6	98.6	61.6	2	2.0	3.6	0.28	1 3/8	5/8	18.0	240	1192	1560	600/540	810	570	
N2CQ76-3MX/S-E	8.79	25.6	131.0	82.3	4	4.0	7.2	0.56	1 3/8	7/8	18.0	273	1192	2260	600/540	2 x 750	570	
N2CQ90-3MX/S-E	9.97	26.2	148.0	91.1	4	4.0	7.2	0.56	1 3/8	7/8	18.0	295	1192	2260	600/540	2 x 750	570	
N2CQ112-3MX/S-E	13.29	30.8	198	118.4	4	4.0	7.2	0.56	1 5/8	7/8	18.0	426	1192	2260	600/540	2 x 750	570	

* Compressor Power based on nominal running conditions using R404A refrigerant for both compressors running. L units : -35°C SST, 32°C Amb, M units : -10°C SST, 32°C Amb. Compressor FLC based on Maximum run current at any condition, for both compressors. Compressor LRA is per compressor. Max Surge amps occur when second compressor starts on delay with the first compressor and fan(s) already running.
** Noise levels measured at 10m from the front air off side of the unit in free field conditions.

GEA Refrigeration
GEA Searle Ltd
20 Davis Way, Newgate Lane, Fareham, PO14 1AR
Tel. +44 (0) 1329 823344, Fax +44 (0) 1329 821242
sales@searle.co.uk, www.searle.co.uk

Searle

Number 272-000-313 Issue May 09/04